

<b>I</b>	
Idle speed adjustment .....	115
Ignition switch .....	14
Indicator	
Drive mode indicator .....	27
Gear position indicator .....	27
Neutral indicator .....	22
Oil/coolant high temperature indicator .....	22
Reverse indicator .....	22
Inspection, pre-ride .....	52
<b>L</b>	
Loading	
Loading guidelines and procedures .....	56
Weight limits .....	55
Lubrication	
(see Engine oil, Gear case oil and differential oil)	
<b>M</b>	
Maintenance	
Precautions .....	102
Schedule .....	100
Modifications .....	60
Multi-function display .....	24
<b>N</b>	
Neutral indicator .....	22
<b>O</b>	
Obstacles, riding over .....	96
Odometer .....	29
Oil (see Engine oil, Gear case oil and differential oil)	
Oil change Indicator .....	28
Oil filler cap .....	43, 117
Oil filter, changing .....	120
Oil/coolant high temperature indicator .....	22
Owner's manual compartment .....	47