

# Maintenance Schedule

ITEMS	FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
		↔	km	150	1000	2000	
			mi	100	600	1200	
		NOTE	HOURS	20	100	200	
	DRIVE SHAFT BOOTS						168
	REAR FINAL GEAR CASE OIL AND DIFFERENTIAL OIL				(RE:EVERY 2 YEARS)		123 125
*	BRAKE FLUID	NOTE 3					145
*	BRAKE SHOE WEAR	NOTE 1					156
	BRAKE SYSTEM						145
	SKID PLATES, ENGINE GUARD						165
*	SUSPENSION						—
*	SPARK ARRESTER				C	C	166
*	NUTS, BOLTS, FASTENERS						—
**	WHEELS/TIRES						158
**	STEERING SHAFT HOLDER BEARINGS						—
**	STEERING SYSTEM						—

- \* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Shop Manual.
- \*\* In the interest of safety, we recommend these items be serviced only by your Honda dealer.