

# Controls & Features


---

## Gearshift Lever

The gearshift lever (1) has four positions: Low (L), Drive (D), Neutral (N), and Reverse (R).

See *Shifting Gears* (page 72) and *Riding in Reverse* (page 79).

### LEFT SIDE OF FUEL TANK



(1) gearshift lever