

# Maintenance Schedule

Maintenance Procedures:

I: inspect and clean, adjust, lubricate, or replace, if necessary

C: clean

A: adjust

L: lubricate

R: replace

ITEMS	FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
		FIRST ⇒	mi	100	600	1200	
			km	150	1000	2000	
		NOTE	HOURS	20	100	200	
* FUEL LINE					I	-	
* THROTTLE OPERATION					I	165	
* CARBURETOR CHOKE					I	167	
AIR CLEANER	NOTE 1				C	C	159
AIR CLEANER HOUSING	NOTE 2				I	I	164
DRAIN TUBE							
SPARK PLUG						I	169
* VALVE CLEARANCE				I	I	I	172
ENGINE OIL				R	R	R	142
ENGINE OIL FILTER				R	R	R	147
* ENGINE IDLE SPEED				I	I	I	168
RADIATOR COOLANT	NOTE 3				I	I	155
* COOLING SYSTEM	NOTE 2				I	I	-

\* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 252 ).