Fuel


Fuel Capacity

Fuel tank capacity: 16.8 $\ensuremath{\$}$ (4.44 US gal , 3.70 Imp gal)

The tank should be refilled as soon as possible when the E segment in the fuel gauge flashes.

Refueling Procedure

Refer to Safety Precautions on page 99.



112 Servicing Your Honda