



# **Driveshaft Boots**

Refer to Safety Precautions on page 99.

#### **FRONT**



#### **REAR**



### (1) driveshaft boots

Check the rubber driveshaft boots (1) for damage or leaking grease. If necessary, have your Honda dealer replace them.

## 160 Servicing Your Honda

