

Basic Operation & Riding

This section gives basic riding instructions, including how to start and stop your engine, how to use the throttle and brakes, and what to do when you're through riding.

To protect your new engine and enjoy optimum performance and service life, refer to Break-in Guidelines (page 203).

Safe Riding Precautions	47
Off-road Use Only	47
Keep Hands and Feet on Controls.....	48
Riding Position & Safety Equipment.....	49
Control Speed.....	49
Use Care on Unfamiliar or Rough Terrain.....	50
Do Not Perform Stunts.....	51
Starting & Stopping the Engine	52
Preparation	53
Starting Procedure	54
Flooded Engine	55
Bank Angle Sensor Ignition Cut-off System	55
How to Stop the Engine	56
Shifting Gears	57
Riding in Reverse	59

(cont'd)