

## CONTENTS

|                                       | Page |
|---------------------------------------|------|
| MAINTENANCE AND REPAIRS .....         | 111  |
| Emission Requirements (USA only)..... | 111  |
| Maintenance Schedule .....            | 112  |
| Maintenance Precautions .....         | 114  |
| Tool Kit.....                         | 116  |
| Fuel System .....                     | 110  |
| Lubrication.....                      | 128  |
| Engine .....                          | 136  |
| Brakes .....                          | 139  |
| Seat Removal .....                    | 147  |
| Wheels and Tires.....                 | 148  |
| Skid Plates .....                     | 153  |
| Spark Arrester .....                  | 154  |
| TRANSPORTING YOUR Sportrax .....      | 156  |
| CLEANING YOUR Sportrax .....          | 159  |
| STORING YOUR Sportrax .....           | 161  |
| SPECIFICATIONS .....                  | 164  |
| WIRING DIAGRAM.....                   | 165  |
| CONSUMER INFORMATION.....             | 166  |
| WARRANTY SERVICE.....                 | 168  |
| SERIAL NUMBERS.....                   | 170  |
| INDEX .....                           | 171  |
| AUTHORIZED MANUALS .....              | 177  |