

Storing Your Honda

Preparation for Storage

Refer to *Safety Precautions* on page 94.

This procedure requires a means for draining and disposing of drained fuel (page 170).

1. Change the engine oil (page 113).
 2. Fill the fuel tank. Make sure the fuel fill cap is properly installed.
 3. Check that the fuel valve is OFF.
 4. Drain the carburetor into an approved petrol container and dispose of it in an approved manner (page 170).
- If storage will last longer than one month, carburetor draining is important to assure proper performance after storage.

⚠ WARNING

Petrol is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

(cont'd)

Tips 167