

Switches



TCS (Traction Control System) OFF switch

Press and hold to turn the TCS on and off.

- The TCS OFF indicator comes on when TCS is turned off.

Passing light control switch

Flashes the high beam headlight.

Headlight dimmer switch

- : High beam
- : Low beam



Handle grip heater switch



Turn signal switch

- The turn signal will automatically stop when you complete the turn.
- When used for a lane change, the turn signal is automatically stopped in 7 seconds or after riding 120 m (131 yards).
- ▲ You can manually cancel the turn signal by pressing the switch in.
- ▲ In some cases, the timing at which the turn signal stops is changed.
- ▲ Always use the recommended tyres to ensure correct automatic cancellation operation.

