


Storage Equipment *(Continued)*

Luggage Tie-down Hook


The luggage tie-down hooks are located on the underside of the rear seat.

Underside of the rear seat



Luggage tie-down hooks

Luggage tie-down hooks



Never use the tie-down hooks to tow or lift the motorcycle.

Removing the Rear Seat  **P.64**