

(Ref.No.) Description	Function
(1) Speedometer	Shows riding speed.
(2) Left turn signal indicator (green)	Flashes when the left turn signal operates.
(3) Tachometer	Shows engine rpm.
(4) Tachometer red zone	Never allow the tachometer needle to enter the red zone, even after the engine has been broken in. CAUTION: * Running the engine beyond recommended maximum engine speed (the beginning of the tachometer red zone) can damage the engine.
(5) Right turn signal indicator (green)	Flashes when the right turn signal operates.