

Starting Procedure

This motorcycle has an automatic choke.
Follow the procedure indicated below.

Any Air Temperature

- Press the starter button with the throttle completely closed.

NOTE:

- The engine will not start if the throttle is fully open (because the electronic control module cuts off the fuel supply).

CAUTION:

- * **The red low oil pressure indicator should go off a few seconds after the engine starts. If the light stays on, stop the engine immediately and check engine oil level. Operating the engine with insufficient oil pressure can cause serious engine damage.**