

MAINTENANCE SCHEDULE

The following Maintenance Schedule specifies all maintenance required to keep your motorcycle in peak operating condition. Maintenance work should be performed in accordance with standards and specifications of Honda by properly trained and equipped technicians. Your Honda dealer meets all of these requirements.

Perform the Pre-ride Inspection (page 57) at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

ITEM	FREQUENCY	WHICHEVER →	ODOMETER READING [NOTE(1)]								REFER TO PAGE	
			COMES FIRST ↓	x 1,000 km	1	6	12	18	24	30		36
				x 1,000 mi	0.6	4	8	12	16	20		24
	NOTE	MONTH		6	12	18	24	30	36			
* FUEL LINE					I		I		I	—		
* THROTTLE OPERATION					I		I		I	83		
AIR CLEANER	(NOTE 2)					R			R	75		
SPARK PLUG			EVERY 12,000 km I, EVERY 24,000km R								80-82	
* VALVE CLEARANCE							I			—		
ENGINE OIL			R		R		R		R	76-79		
ENGINE OIL FILTER			R		R		R		R	77-79		
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	84		
RADIATOR COOLANT	(NOTE 3)				I		I		R	29-30		
* COOLING SYSTEM					I		I		I	—		
SECONDARY AIR SUPPLY SYSTEM					I		I		I	—		