

ITEM	FREQUENCY	NOTE	ODOMETER READING [NOTE (1)]								Refer to page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
			MONTH		6	12	18	24	30	36	
DRIVE CHAIN				EVERY 1,000 km (600 mi) I, L						70	
DRIVE CHAIN SLIDER					I			I		I	76
BRAKE FLUID		(NOTE 4)			I	I	R	I	I	R	13
BRAKE SHOE/PAD WEAR					I	I	I	I	I	I	78, 79
BRAKE SYSTEM				I		I		I		I	13
* BRAKE LIGHT SWITCH						I		I		I	91
* HEADLIGHT AIM						I		I		I	—
CLUTCH SYSTEM				I	I	I	I	I	I	I	18
SIDE STAND						I		I		I	77
* SUSPENSION						I		I		I	—
* NUTS, BOLTS, FASTENERS				I		I		I		I	—
** WHEELS/TYRES						I		I		I	—
** STEERING HEAD BEARINGS				I		I		I		I	—