


## CRANKCASE BREATHER

(Refer to Maintenance Precautions on page 58).

1. Remove the drain plug (1) from the tube and drain deposits.
2. Reinstall the drain plug.

### NOTE:

- \* Service more frequently when ridden in rain or at full throttle.



(1) Drain plug