

<b>(Ref.No.) Description</b>	<b>Function</b>
(11) Fuel indicator (orange)	Lights when there is only few fuel left in the fuel tank. The amount of fuel left in the tank when lights and with the vehicle set upright is approximately: 3.5 l (0.92 US gal , 0.77 Imp gal) Should also light for a few seconds and then go off when the ignition switch is turned ON.