
Odometer/Tripmeter/Digital clock Display

The display (1) has three functions: odometer, tripmeter and digital clock.


The tripmeter has two sub modes, "TRIP 1" and "TRIP 2".

Push the button (2) to select the "ODO", "TRIP 1", "TRIP 2" or "CLOCK" mode.

To reset the tripmeter, push and hold the button with the display in the "TRIP 1" or "TRIP 2" mode.



 Odometer/Tripmeter/Digital clock display
Odometer/Tripmeter/Digital clock select and reset button



Tripmeter reset

