

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
	FINAL DRIVE OIL				I			I		R	34, 81
	BRAKE FLUID	NOTE (4)			I	I	R	I	I	R	23
	BRAKE SHOES/PADS WEAR				I	I	I	I	I	I	96, 97
	BRAKE SYSTEM			I		I		I		I	22, 96, 97
*	BRAKELIGHT SWITCH					I		I		I	104
*	HEADLIGHT AIM					I		I		I	53
	CLUTCH SYSTEM			I	I	I	I	I	I	I	26
	SIDE STAND					I		I		I	86
*	SUSPENSION					I		I		I	85
*	NUTS, BOLTS, FASTENERS			I		I		I		I	—
**	WHEELS/TYRES			I	I	I	I	I	I	I	—
**	STEERING HEAD BEARINGS			I		I		I		I	—