## Installation:

- I. Reinstall in the reverse order of removal.

  Be sure to connect the positive (+)
  terminal first, then the negative (-)
  terminal.
- 2. Check all bolts and other fasteners are secure.