

| ITEM                      | FREQUENCY | WHICHEVER →<br>COMES FIRST ↓<br>NOTE | ODOMETER READING [NOTE (1)]  |     |    |    |    |    |    |        | REFER<br>TO PAGE |
|---------------------------|-----------|--------------------------------------|------------------------------|-----|----|----|----|----|----|--------|------------------|
|                           |           |                                      | x 1,000 km                   | 1   | 6  | 12 | 18 | 24 | 30 | 36     |                  |
|                           |           |                                      | x 1,000 mi                   | 0.6 | 4  | 8  | 12 | 16 | 20 | 24     |                  |
|                           |           | MONTH                                |                              | 6   | 12 | 18 | 24 | 30 | 36 |        |                  |
| DRIVE CHAIN               |           |                                      | EVERY 1,000 km (600 mi) I, L |     |    |    |    |    |    |        | 61-66            |
| BRAKE FLUID               |           | (NOTE 4)                             |                              | I   | I  | R  | I  | I  | R  | 14-15  |                  |
| BRAKE SHOE/PAD WEAR       |           |                                      |                              | I   | I  | I  | I  | I  | I  | 68, 69 |                  |
| BRAKE SYSTEM              |           |                                      | I                            |     | I  |    | I  |    | I  | 14-17  |                  |
| * BRAKE LIGHT SWITCH      |           |                                      |                              |     | I  |    | I  |    | I  | 77     |                  |
| * HEADLIGHT AIM           |           |                                      |                              |     | I  |    | I  |    | I  | --     |                  |
| CLUTCH SYSTEM             |           |                                      | I                            | I   | I  | I  | I  | I  | I  | 18-19  |                  |
| SIDE STAND                |           |                                      |                              |     | I  |    | I  |    | I  | 67     |                  |
| * SUSPENSION              |           |                                      |                              |     | I  |    | I  |    | I  | --     |                  |
| * NUTS, BOLTS, FASTENERS  |           |                                      | I                            |     | I  |    | I  |    | I  | --     |                  |
| ** WHEELS/TYRES           |           |                                      | I                            | I   | I  | I  | I  | I  | I  | --     |                  |
| ** STEERING HEAD BEARINGS |           |                                      | I                            |     | I  |    | I  |    | I  | --     |                  |