<b>VLA</b>	UNTENANCE		
Page	e	Pag	e
45	MAINTENANCE	87	CLEANING
46	Maintenance Schedule		
49	Tool Kit		STORAGE GUIDE
50	Serial Numbers	89	9
50	Colour Label	91	Removal from Storage
51	Maintenance Precautions		
52	Air Cleaner	92	SPECIFICATIONS
53	Crankcase Breather		
54	Engine Oil	96	NOISE CONTROL SYSTEM
58	Spark Plugs		(AUSTRALIA ONLY)
60	Throttle Operation		
61	Idle Speed		
62			
68	Side Stand		
69	Brake Pad Wear		
70			
71	Wheel Removal		
76			
78	1 0		
79	•		
82	Bulb Replacement		