


The tripmeter has two sub modes, "TRIP 1" and "TRIP 2".

Push the odometer/tripmeter/digital clock select and reset button (2) to select the "ODO", "TRIP 1", "TRIP 2" and "digital clock" mode.

To reset the tripmeter, push and hold the odometer/tripmeter/digital clock select and reset button with the display in the "TRIP 1" or "TRIP 2" mode.



(2) Odometer/tripmeter/digital clock select and reset button

