

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]							Refer to page	
			× 1,000 km	1	6	12	18	24	30		36
			× 1,000 mi	0.6	4	8	12	16	20		24
		MONTH		6	12	18	24	30	36		
DRIVE CHAIN			I, L EVERY 1,000km (600mi)							94	
DRIVE CHAIN SLIDER					I		I		I	100	
BRAKE FLUID		NOTE (3)		I	I	R	I	I	R	27	
BRAKE PAD WEAR				I	I	I	I	I	I	110	
BRAKE SYSTEM			I		I		I		I	27, 110	
* BRAKE LIGHT SWITCH					I		I		I	—	
* HEADLIGHT AIM					I		I		I	—	
CLUTCH SYSTEM					I		I		I	30	
CLUTCH FLUID		NOTE (3)		I	I	R	I	I	R	30	
SIDE STAND					I		I		I	102	
* SUSPENSION					I		I		I	101	
* NUTS, BOLTS, FASTENERS			I		I		I		I	—	
** WHEELS/TYRES					I		I		I	—	
** STEERING HEAD BEARINGS			I		I		I		I	—	