

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]							Refer to page	
			× 1,000 km	1	6	12	18	24	30		36
			× 1,000 mi	0.6	4	8	12	16	20		24
		NOTE	MONTH		6	12	18	24	30	36	
DRIVE CHAIN				I, L EVERY 1,000 km (600 mi)							94
DRIVE CHAIN SLIDER					I			I		I	100
BRAKE FLUID		NOTE (3)			I	I	R	I	I	R	27
BRAKE PAD WEAR					I	I	I	I	I	I	110
BRAKE SYSTEM				I		I		I		I	27, 110
* BRAKE LIGHT SWITCH						I		I		I	—
* HEADLIGHT AIM						I		I		I	—
CLUTCH SYSTEM						I		I		I	30
CLUTCH FLUID		NOTE (3)			I	I	R	I	I	R	30
SIDE STAND						I		I		I	102
* SUSPENSION						I		I		I	101
* NUTS, BOLTS, FASTENERS				I		I		I		I	—
** WHEELS/TYRES						I		I		I	—
** STEERING HEAD BEARINGS				I		I		I		I	—