


(Ref.No.) Description	Function
(10) Immobilizer system (HISS) indicator (red)	This indicator lights for a few seconds when the ignition switch is turned ON and the engine stop switch is at  (RUN). It will then go off if the properly-coded key has been inserted. If an improperly-coded key has been inserted, the indicator will remain on and the engine will not start. This indicator continues to flash every 5 seconds during 24 hours when the ignition switch is turned off. After this period, the indicator automatically switches off (page 47).
(11) Left turn signal indicator (green)	Flashes when the left turn signal operates.
(12) Speedometer	Shows riding speed. This shows your speed in kilometers per hour (km/h) and/or miles per hour (mph) depending on the type.