

(Ref.No.) Description	Function
(10) Fuel indicator (amber)	Lights when there is only few fuel left in the fuel tank. The amount of fuel left in the tank when lights and with the vehicle set upright is approximately: 4.5 l (1.19 US gal , 0.99 Imp gal)
(11) Multi-function display	The display includes the following functions; This display shows the initial display (page 16).
Odometer	Shows accumulated mileage (page 19).
Tripmeter	Shows mileage per trip (page 19).
Coolant temperature meter	Shows coolant temperature (page 18).
(12) Multi-function select and reset button	Resets the tripmeter or select the operation mode: tripmeter, odometer and coolant temperature meter (page 19).