


## Odometer/Tripmeter/Coolant temperature meter


The display (1) has three functions: odometer, tripmeter and coolant temperature meter.

Push the button (2) to select “ODO” (Odometer), “TRIP” (Tripmeter) and “TEMP” (Coolant temperature meter) mode.

To reset the tripmeter, push and hold the button when the display is in the “TRIP” mode.




ODO



TRIP

TEMP

Tripmeter  
reset



- (1) Multi-function display
- (2) Multi-function select and reset button