


Flooded Engine

If the engine fails to start after repeated attempts, it may be flooded with excess fuel. To clear a flooded engine.

1. Leave the engine stop switch set to  (RUN).
2. Push the choke knob down all the way to fully OFF (B).
3. Open throttle fully.
4. Press the starter button for 5 seconds.
5. Then follow the normal starting procedure.
6. If the engine start, then open the throttle slightly if idling is unstable.
If the engine does not start, wait for 10 seconds, then follow steps 1–5 again.

Ignition Cut Off

Your motorcycle is designed to automatically stop the engine and fuel pump if the motorcycle is over-turned (a banking sensor cuts off the ignition system). Before restarting the engine, you must turn the ignition switch to the OFF position and then back to ON.