



Gauges, Indicators & Displays

9	turn signal indicator (amber)	Flashes when either turn signal operates.
10	neutral indicator (green)	Lights when the transmission is in neutral. <i>Lamp Check.</i>
11	high beam indicator (blue)	Lights when the headlight is on high beam. <i>Lamp Check.</i>
12	multi-function select and reset button	Selects display of the odometer, tripmeter and coolant temperature meter (page 28).



18 Instruments & Controls

