



- ③ Turn the fuel fill cap counterclockwise and remove the cap.

Arrow marks



Fuel fill cap



Fuel filler opening  
Filler neck plate—  
Fuel level (max)

## Closing the Fuel Fill Cap

- ① Install and tighten the fuel fill cap firmly by turning it clockwise.  
► Make sure that the arrow marks on the cap and fuel tank are aligned.
- ② Close the fuel lid until it locks.  
► Make sure that the fuel lid is closed securely.

## ! WARNING

Petrol is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

Do not fill with fuel above the plate.