

## Pre-ride Inspection

To ensure safety, it is your responsibility to perform a pre-ride inspection and make sure that any problem you find is corrected. A pre-ride inspection is a must, not only for safety, but because having a breakdown, or even a flat tyre, can be a major inconvenience.

Check the following items before you ride your scooter:

- Fuel level-Fill fuel tank when necessary. ➔ P. 36
- Throttle-Check for smooth opening and full closing in all steering positions. ➔ P. 78
- Engine oil level-Add engine oil if necessary. Check for leaks. ➔ P. 66
- Coolant level-Add coolant if required. Check for leaks. ➔ P. 70

- Brakes-Check operation;  
Front: check brake fluid level and pads wear. ➔ P. 72, 73  
CBS: check brake fluid level. ➔ P. 72  
Rear: check shoes wear and freeplay, adjust if necessary. ➔ P. 74, 76
- Lights and horn-Check that lights, indicators and horn function properly.
- Side stand ignition cut-off system-Check for proper function. ➔ P. 31, 77
- Wheels and tyres-Check condition, air pressure and adjust if necessary. ➔ P. 53