

Serial Numbers

The frame and engine serial numbers uniquely identify your scooter and are required in order to register your scooter. They may also be required when ordering replacement parts.

The frame number is stamped on the rear of the frame body inside the centre compartment.

The engine number is stamped on the left side of the crankcase.

You should record these numbers and keep them in a safe place.

