

Maximum Weight Limit .....	16, 106
Modifications .....	15
<b>O</b>	
Odometer .....	21, 97
Oil	
Engine .....	51, 66
Overheating .....	82
<b>P</b>	
Parking .....	13
Parts Location .....	18
Petrol .....	14, 36, 106
PGM-FI (Programmed Fuel Injection)	
malfunction indicator lamp (MIL) ....	22, 83
Protective Apparel .....	11
<b>R</b>	
Recommended .....	
Coolant .....	52
Fuel .....	36
Oil .....	51
Refuelling .....	36
<b>S</b>	
Safety Precautions .....	11
Seat .....	38
Serial Numbers .....	105
Shutter .....	26
Side Stand .....	77
Side Stand Ignition Cut-off System .....	31, 77
Specifications .....	106
Speedometer .....	20
Start Button .....	24, 31
Starting the Engine .....	31
Starting the Scooter .....	34
Steering Lock .....	25