

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to pages
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		NOTE	MONTH		6	12	18	24	30	36	
	DRIVE CHAIN			EVERY 1,000 km (600 mi) I, L							75
	DRIVE CHAIN SLIDER				I			I		I	81
	BRAKE FLUID	NOTE (3)			I	I	R	I	I	R	18
	BRAKE PAD WEAR				I	I	I	I	I	I	92
	BRAKE SYSTEM				I			I		I	18, 92, 93
*	BRAKE LIGHT SWITCH						I			I	99
*	HEADLIGHT AIM						I			I	—
	CLUTCH SYSTEM				I	I	I	I	I	I	22
	SIDE STAND						I			I	83
*	SUSPENSION						I			I	82
*	NUTS, BOLTS, FASTENERS				I			I		I	—
**	WHEELS/TYRES						I			I	—
**	STEERING HEAD BEARINGS				I			I		I	—