


EQUIPMENT AND CONTROLS Control Location (XL200 SUPER FARMER)



- (1) Speedometer
- (2) Ignition switch
- (3) Tachometer
- (4) Front brake lever
- (5) Throttle grip
- (6) Engine stop switch
- (7) Headlight switch
- (8) Rear brake pedal
- (9) Foot pegs
- (10) Kick starter pedal
- (11) Clutch lever
- (12) Headlight dimmer switch
(above)
Turn signal switch (center)
Horn button (below)
- (13) Fuel filler cap
- (14) Gear change pedal

(XL200 SUPER FARMER)