
DESCRIPTION

PARTS LOCATION

- (1) Speedometer
- (2) Ignition switch
- (3) Front brake lever
- (4) Throttle grip
- (5) Engine stop switch
- (6) Rear brake pedal
- (7) Kickstarter pedal
- (8) Foot pegs
- (9) Choke knob
- (10) Clutch lever
- (11) Headlight dimmer switch
- (12) Turn signal switch (above)
Horn button (below)
- (13) Fuel filler cap
- (14) Gear change pedal
- (15) Side stand