

CLEANING

Clean your motorcycle regularly to protect the surface finishes and inspect for damage, wear, and oil seepage.

CAUTION

* *Avoid spraying high pressure water (typical in coin-operated car washes) at the following areas:*

| | |
|------------------------|---------------------------|
| <i>Wheel Hubs</i> | <i>Ignition Switch</i> |
| <i>Muffler Outlets</i> | <i>Steering Lock</i> |
| <i>Under Fuel Tank</i> | <i>Drive Chain</i> |
| <i>Under Seat</i> | <i>Handlebar switches</i> |

1. After cleaning, rinse the motorcycle thoroughly with plenty of clean water. Strong detergent residue can corrode alloy parts.
2. Dry the motorcycle, start the engine, and let it run for several minutes.
3. Test the brakes before riding the motorcycle in traffic. Several applications may be necessary to restore normal braking performance.
4. Lubricate the drive chain immediately after washing the motorcycle.

WARNING

* *Braking performance may be impaired immediately after washing the motorcycle.*

STORAGE

Storage for more than a month, or winter storage requires preventive maintenance to prevent deterioration of the fuel, tires, battery; and corrosion.

See your authorized Honda dealer for this service.