

Flooded Engine

If the engine fails to start after repeated attempts, it may be flooded with excess fuel. To clear a flooded engine, push the choke lever down to Fully OFF (C). Turn the engine stop switch to ☒ (OFF). Pull and hold the manual decompressor lever. Open the throttle fully and crank the engine several times with the kickstarter. Release the decompressor lever, turn the engine stop switch to ○ (RUN) and follow the "High Air Temperature" Starting Procedure (page 55).

RUNNING-IN

Help assure your motorcycle's future reliability and performance by paying extra attention to how you ride during the first operating day or 25 km (15 miles).

During this period, avoid full-throttle starts and rapid acceleration.