



Suspension

5. Be sure the oil level is the same in both fork tubes.
6. Clean and dry the fork springs with a lint-free cloth. Install the fork springs. Oil the fork cap O-rings and install the fork caps. Torque the fork caps to:
16 lbf·ft (22 N·m , 2.2 kgf·m)



Front Suspension Damping

Rebound Damping

The rebound damping adjuster has at least 12 positions. Turning the adjuster screw one full turn advances the adjuster 6 positions.

Always start with the full hard position when adjusting damping.



(cont'd)

