


Headlight & Taillight

Taillight Bulb


LEFT REAR



- (1) screws
- (2) lens



REAR



(3) bulb

1. Remove the two screws (1).
2. Pull the lens off. Replace the bulb (3) with a new one.
3. Reinstall the lens.

