

FEATURES

(Not required for operation)


STEERING LOCK

The steering can be locked when the ignition switch (1) is in "LOCK" position.

To lock the steering, turn the handlebars all the way to the left or right, turn the key (B) to LOCK while pushing in. Remove the key.

▲WARNING

*** Do not turn the key to LOCK while riding the motorcycle; loss of vehicle control will result.**



(1) Ignition key

(A) Push in
(B) Turn to LOCK