


Montage de la transmission



- (1) M2 (13T)
- (2) M4 (28T)
- (3) M3 (15T)
- (4) M5 (22T)
- (5) MOYEU DE TRANSMISSION  
PRIMAIRE/M1 (15T)
- (6) C2 (31T)
- (7) C4 (28T)
- (8) C3 (30T)
- (9) C5 (22T)
- (10) C1 (42T)
- (11) MOYEU DE TRANSMISSION  
SECONDAIRE