

# Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

<b>Importance of Maintenance</b> .....	P. 65	Adjusting the Windscreen Height .....	P. 90
<b>Maintenance Schedule</b> .....	P. 66	<b>Other Replacement</b> .....	P. 91
<b>Maintenance Fundamentals</b> .....	P. 69	Replacing the Honda SMART Key Battery.....	P. 91
<b>Tool</b> .....	P. 78		
<b>Removing &amp; Installing Body Components</b> ..	P. 79		
Battery .....	P. 79		
Battery Cover .....	P. 80		
Front Lid.....	P. 81		
<b>Engine Oil</b> .....	P. 82		
<b>Coolant</b> .....	P. 84		
<b>Brakes</b> .....	P. 86		
<b>Side Stand</b> .....	P. 88		
<b>Throttle</b> .....	P. 89		
<b>Other Adjustments</b> .....	P. 90		