

## FUEL SYSTEM

---

Remove the throttle valve and remove the jet needle (Page 4–6).

Change the jet needle clip position from the 3rd groove (standard) to the 2nd groove.

Install the jet needle and install the throttle valve.

Assemble and install the carburetor.  
Start the engine and adjust the idle speed at high altitude to ensure proper high altitude operation.

### CAUTION

*Sustained operation below 5,000 feet (1,500 m) with the high altitude settings may cause engine overheating and engine damage. Install the #95 main jet, return the jet needle clip position to the 3rd groove. When riding below 5,000 feet (1,500 m).*

