

# LUBRICATION

## LUBRICATION POINTS

Use general purpose grease when other specification is given. Apply oil or grease to any 2 sliding surfaces and cables not shown here.

