

Horn Button



The horn is used to alert other motorists.
To operate, push the horn button (3).

RESET Button

The RESET button is used for the following purposes:

- To reset the tripmeter A & B (page 29)
- To select brightness of the display (page 30).
- To adjust time (page 31)
- To change unit of the speedometer, odometer and tripmeter (page 34)
- To change unit of the temperature meter (page 35)