

Odometer [TOTAL] & Tripmeter [TRIP A/B] & Stopwatch \( \bigstyle{\textit{P}}\)P.20

When the coolant is over specified temperature, the segment H flashes.

If the segment H flashes while riding: P.107

Current fuel mileage, Average fuel mileage [AVG], Fuel consumption, and Average speed [AVG] 

P.24

## Fuel gauge

Remaining fuel when only 1st (E) segment starts flashing: approximately 0.50 US gal (1.9 L)

If the fuel gauge indicator flashes in a repeat pattern or turns off: P.110

