

Engine

Number	132
Oil.....	64, 84
Oil Filter	86
Overheats	107
Starting	45
Stop Switch.....	42, 125
Stopping	125
Will Not Start	106

Environment	131
--------------------------	-----

Equipment

Document Bag.....	50
Helmet Holder	49
Owner's Manual.....	125
Tool	50

F

Flooded Engine	45
-----------------------------	----

Front Seat	76
-------------------------	----

Front Turn Signals/Position Lights	120
---	-----

Fuel

Average Fuel Mileage Meter	19, 25
Consumption Meter	19, 26
Current Fuel Mileage Meter	19, 25

Gauge	19, 110
Recommended	48, 146
Remaining	19
Tank Capacity	48, 146

Fuses	63, 121
--------------------	---------

G

Gasohol	139
----------------------	-----

Gasoline	48
-----------------------	----

H

Headlight	119
------------------------	-----

Headlight Aim	103
----------------------------	-----

Headlight Dimmer Switch	42
--------------------------------------	----

Helmet Holder	49
----------------------------	----

High Beam Indicator	39
----------------------------------	----

Honda Contacts	143
-----------------------------	-----

Horn Button	42
--------------------------	----

I

Ignition Cut-off System

Banking Sensor.....	125
Side Stand.....	93

Ignition Key	124
---------------------------	-----