The average fuel mileage and fuel consumption will be based on tripmeter A.

• Current fuel mileage:

Current instant fuel mileage. If your speed is less than 5 mph (7 km/h), " --- " is displayed.

When " --- " is displayed at speeds above 5 mph (7 km/h), go to your dealer for service.

- Average fuel mileage: Average fuel mileage since tripmeter A was reset. When " --- " is displayed, go to your dealer for service.
- Fuel consumption:

Total fuel consumption since tripmeter A was reset. When " ---- " is displayed, go to your dealer for service.

► To reset the average fuel mileage and fuel consumption: <a>P.22